

NC ADJUSTMENT

The NC adjustment is based on source (diffuser) - receiver (occupant) distance. Sound data in the tables is based on 10' distance. This graph shows sound level adjustment as the source-receiver distance is changed.

